

esatto

This little Quick Start Guide
is everything you need for your
ETLW102B Top Load Washing
Machine—say goodbye to those
dirty clothes piling up!



Get ready to use your ETLW102B Top Load Washing Machine!

Installing Your Washing Machine

- 1 Choose a solid and level surface that is away from direct sunlight.
- 2 Remove the cardboard carton and styrofoam packaging.
- 3 Lift the washing machine and remove the base packaging.
- 4 Remove the tape securing the power supply cord and drain hose.
- 5 Remove the inlet hose from the drum.

Please refer to the user manual page 7–9 for more detailed installation instructions.

Preparing the Machine

Before using the washing machine, you must perform one complete cycle without any clothes inside using the following steps:

- 1 Connect the power source and water.
- 2 Insert a small amount of detergent into the detergent drawer and close it.
- 3 Power on the machine and select a program and water level.
- 4 Press the 'Start/Pause' button to begin the wash cycle..
- 5 After the machine has completed its full cycle, the machine is now ready for use..

Please refer to the user manual page 10–15 for more detailed operation instructions.

Product Details

Dimensions (W, D, H mm) / **601 × 630 × 1000**
Energy Rating (MEPS/WELS) / **2 Stars / 3 Stars**
Weight (Net/Gross) / **45kg / 53kg**
Warranty / **2 Years**

Register your Esatto product online for a free additional year esatto.house/warranty

Washing Programs

- **Mix**
Suitable to wash cotton, linen, flax. jute clothes
- **Normal (Standard)**
Standard fabric washing program, suitable to wash ramie cotton fabric. Wash for once, rinsing for twice, the spin time is a little long.
- **Jeans**
This cycle is suitable to wash heavily stained/wearable clothes, particularly denim.
- **Soft**
The tempo is soft, slow washing and spinning speed, to make the lightest wear and deformation.
- **Strong**
The wash time is longer, the stream is Stronger, so the washing effect is better.
- **Heavy**
Suitable to wash heavily stained/wearable clothes.
- **Quick 15'**
Suitable to wash light stained clothes and summer clothes.



Please refer to the user manual page 12, 13 & 15 for more detailed washing program instructions.

Get in Touch

Need help? Contact our friendly support team via the contact details below.

Phone / **1300 11 4357**

Email / support@residentialgroup.com.au

 @esatto.house  @esatto.house

www.esatto.house