

**esatto**

This little Quick Start Guide  
is everything you need to get  
started so that your EDWI605S  
60cm Integrated Dishwasher  
does all of your dirty work, literally!



esatto

# Get ready to use your EDWI605S 60cm Integrated Dishwasher!


## Installation

This appliance is integrated and does not include a door panel. Before installing this product please contact a kitchen cabinetmaker to organise a door panel in your chosen finish.

For a complete installation guide, refer to pages 8–13 of your user manual.

## The Controls

- 1 Program indicator lights
- 2 Program button
- 3 Delay indicator lights
- 4 Delay Start button  
3, 6 & 9 hours
- 5 Extra Drying function button
- 6 Extra Drying indicator light
- 7 On/Off power button
- 8 Warning indicator lights  
Rinse Aid & Program End



## Product Details

Dimensions (W, D, H mm) / **598 × 550 × 815**  
Energy Rating (MEPS/WELS) / **3 / 4.5 Stars**  
Capacity / **12 Place Settings**  
Warranty / **2 Years**

Register your Esatto product online for a free additional year [esatto.house/warranty](http://esatto.house/warranty)

## Program Cycles

- **Rapid**  
A quick 30 minute wash suitable for lightly soiled dishes—does not include drying stage.
- **Super 90'**  
A fast 90 minute daily program for lightly soiled dishes.
- **ECO**  
A standard program for daily use with reduced energy and water consumption.
- **Heavy**  
A program suitable for heavily soiled dishes.
- **Intensive**  
A hot intensive program suitable for heavily soiled dishes and cookware.

Note: To assist drying, we recommend partially opening the door after the program has finished.

For a complete guide on using your dishwasher, refer to your user manual on pages 6–7 & 14–20.

## Get in Touch

Need help? Contact our friendly support team via the contact details below.  
Phone / **1300 11 4357**  
Email / [support@residentiagroup.com.au](mailto:support@residentiagroup.com.au)

@esatto.house @esatto.house

[www.esatto.house](http://www.esatto.house)