

**esatto**

**This little Quick Start Guide is everything  
you need to start chilling with your  
EUF92W & EUF92S 84L Upright Freezer!**



# Ice to meet you! Let's get started with your EUF92W or EUF92S 84L Upright Freezer!

## The Thermostat Controls

Your fridge has one control for regulating the temperature. The temperature control is located at the rear, near the compressor. Depending on your room's ambient temperature, you may need to adjust the temperature setting to achieve your desired temperature.

The number on the thermostat dial does not directly represent the temperature. Instead, the larger the number is, the lower the freezer interior temperature will be.

- Dial position 1–2 will set your freezer to approximately -12°C
- Dial position 3–4 will set your freezer to approximately -15°C
- Dial position 5–6 will set it to approximately -20°C

## Your Bar Fridge

1. Storage baskets (x3)
2. Door
3. Foot
4. Top hinge assembly
5. Bottom hinge assembly + foot



## Installation Tips

- When starting up for the first time, keep the freezer upright for 2 hours before connecting it to a power supply.
- When you install your appliance, set the thermostat knob to position 6 for the first 24–48 hours, after which you can set it to the level that best suits your needs. It is the best to wait 24 hours before adding food.

Please refer to your user manual pages 9–10 for detailed instructions.

## Get in touch

Need help? Contact our friendly support team via the contact details below.

Phone / **1300 11 4357**

Email / [support@residentiagroup.com.au](mailto:support@residentiagroup.com.au)

How was your Esatto experience?

Share your story at [esatto.house/review](https://esatto.house/review)

## We're on socials!

 @esatto.house

 @esatto.house

## Product Details

Size (mm) / **860H x 501W x 540D**

Energy Rating / **3 Stars**

Warranty / **2 Years**