

**esatto**

This little Quick Start Guide is everything you need for your EWC46 45 Bottle Wine Chiller so you can sip back and smell the rosé!



## Ready to use your EWC46 Wine Chiller? It isn't good to keep things bottled up.

### Installation

Before installing your new Wine Chiller please read all safety instructions in the user manual.

Place the Wine Chiller on a sturdy, level floor for quiet operation. If it is to be placed on carpet, support it with a wooden board underneath.

This appliance is designed to be freestanding only and should not be recessed or built in.

### Before First Use

- The wine cabinet must be rested for at least four hours before connecting power.
- Powering on: Press and hold the POWER button for three seconds to turn the appliance on.
- Cooling down: When you first switch on the wine chiller, the compressor will run continuously until the wine chiller reaches the set temperature. During this period of time, try not to open the door frequently or place bottles inside the appliance. After about 3–4 hours, you can start loading the wine chiller.
- Note: You may notice an odour when you first switch on the wine chiller. This is due to the parts being new and is no cause for concern. The odour will subside as the wine chiller starts to cool.

### Product Details

Dimensions (W, D, H mm) / **545 × 565 × 855**

Capacity/ **45 Bottles**

Warranty / **2 Years**

### We're on Socials!

 @esatto.house  @esatto.house

### Recommended Temperatures

- **Bordeaux Red:** 18° C
- **Burgundy / Bordeaux Red:** 16° C
- **Port:** 15° C
- **Young Burgundy Red:** 14° C
- **Young Red Wines / Rosé:** 12° C
- **Aged White Wines / Chardonnay:** 10° C
- **Sherry:** 7–9° C
- **Young White Wines:** 5–7° C

### Operating Instructions

You can set and adjust the temperature in the Wine Chiller to anywhere within the cooling range (5° C – 18° C) using the + and – buttons on the Control Panel to set the desired setting.

- **Light:**  
The light button will switch the interior light On and OFF.
- **Switching between °C & °F:**  
Press and hold both LIGHT and POWER buttons simultaneously to switch between displaying the temperature in Celsius or Fahrenheit

For more tips on operating your Wine Chiller, please see page 10 of your User Manual.

### Get in Touch

Need help? Contact our friendly support team via the contact details below.

Phone / **1300 11 4357**

Email / [support@residentiagroup.com.au](mailto:support@residentiagroup.com.au)

How was your esatto experience?

Share your story at [esatto.house/review](https://esatto.house/review)